

LENNOX FURNACE WIRING SCHEMATIC Textbook

lennox furnace wiring schematic is an essential guide for HVAC technicians, homeowners, and service professionals aiming to understand the wiring setup of Lennox furnaces. Proper knowledge of the wiring schematic ensures safe installation, efficient troubleshooting, and effective maintenance of the heating system. Whether you're a seasoned technician or a DIY enthusiast, mastering the Lennox furnace wiring schematic can help you diagnose issues promptly and ensure your furnace operates reliably during cold seasons. This comprehensive guide provides detailed insights into the wiring diagrams, key components, troubleshooting tips, and best practices associated with Lennox furnaces.

Understanding the Importance of a Lennox Furnace Wiring Schematic

Why a Wiring Schematic is Essential

A wiring schematic offers a visual representation of how electrical components are interconnected within the furnace. It is crucial because:

- It helps identify the correct wiring paths during installation or repair.
- It simplifies troubleshooting by highlighting potential problem areas.
- It ensures safety by providing clear wiring instructions, reducing the risk of electrical faults.
- It aids in understanding the operation of various furnace components, such as the blower motor, limit switches, and control boards.

Common Components in Lennox Furnaces

A typical Lennox furnace wiring schematic includes several key components:

- Thermostat connections (R, C, W, Y, G)
- Control board (main circuit control)
- Limit switches (safety devices)
- Inducer motor (exhaust fan)
- Blower motor
- Ignition system (electronic or pilot)
- Gas valve

- Transformer

Understanding how these components connect is vital for safe and efficient furnace operation.

Decoding the Lennox Furnace Wiring Diagram

Basic Wiring Diagram Overview

A typical Lennox furnace wiring schematic can be divided into several sections:

- Power supply connections
- Control circuit wiring
- Safety devices wiring
- Gas and ignition wiring
- Blower motor wiring

Each section has specific wiring requirements that ensure proper functioning.

Power Supply Connections

- Line Voltage Input: Usually 120V or 240V, depending on the furnace model.
- Transformer: Steps down voltage for control circuits, typically 24V.
- Grounding: Proper grounding is critical for safety and to prevent electrical faults.

Control Circuit Wiring

- Thermostat: Sends signals via R (power), C (common), W (heat), Y (cooling), and G (fan).
- Control Board: Receives signals from the thermostat and activates the appropriate components such as the gas valve and blower motor.
- Relays and contactors: Switch power to different furnace parts based on control signals.

Safety Devices Wiring

- Limit Switches: Interrupt power if the furnace overheats.
- Pressure Switches: Protect against venting issues.
- Flame Rollout Switches: Prevent unsafe ignition conditions.

Gas and Ignition System Wiring

- Gas Valve: Controlled via relay; only energized when ignition is required.
- Ignition System: Electronic igniters or pilot lights are wired to the control board and ignition transformer.

Blower Motor Wiring

- The blower motor is wired to the control board, with separate wiring for high and low speeds if applicable.
- G wire from thermostat controls fan operation.

Step-by-Step Guide to Reading and Using a Lennox Furnace Wiring Schematic

Step 1: Identify the Components

- Locate the control board, thermostat connections, safety switches, blower motor, gas valve, and ignition system on the schematic.
- Familiarize yourself with standard symbols used in wiring diagrams.

Step 2: Trace the Power Path

- Follow the line voltage from the power source to the control board.
- Ensure the transformer is correctly wired to step down voltage.

Step 3: Understand the Control Circuit

- Examine how signals from the thermostat activate the control board.
- Check relay wiring and contact points for continuity.

Step 4: Review Safety Device Wiring

- Confirm that limit switches and pressure switches are wired correctly to interrupt power in unsafe conditions.

Step 5: Verify the Ignition and Gas Valve Wiring

- Ensure the ignition system is wired correctly with proper grounding.
- Confirm that the gas valve wiring includes the necessary safety interlocks.

Step 6: Check the Blower Motor Wiring

- Verify wiring for different fan speeds.
- Make sure G (fan) wire from the thermostat is properly connected.

Common Wiring Troubleshooting Tips for Lennox Furnaces

1. Check Power Supply and Transformer

- Verify if the furnace is receiving power.
- Test the transformer output for 24V AC.

2. Inspect Thermostat Wiring

- Confirm thermostat wires are correctly connected to the R, C, W, Y, and G terminals.
- Replace faulty thermostats if wiring is intact.

3. Examine Control Board and Relays

- Look for signs of damage or corrosion.
- Test relays for proper operation.

4. Test Safety Switches and Limit Devices

- Use a multimeter to check continuity.
- Replace faulty safety devices immediately.

5. Verify Ignition and Gas Valve Wiring

- Ensure proper grounding.
- Check for loose or broken wires.

6. Confirm Blower Motor Operation

- Test motor wiring and capacitor.
- Replace if motor does not run when called for.

Best Practices for Wiring a Lennox Furnace

- Always disconnect power before working on the furnace to prevent electrical shock.
- Follow the manufacturer's wiring diagram meticulously.
- Use appropriate wire gauge and connectors.
- Secure wiring to prevent vibration and wear.
- Label wires during installation for easier troubleshooting later.
- Test all connections after installation or repair to ensure safety and functionality.
- Consult Lennox technical manuals and wiring schematics specific to your furnace model for accurate wiring procedures.

FAQs About Lennox Furnace Wiring Schematics

Q1: Where can I find the wiring schematic for my Lennox furnace?

A1: The wiring schematic is typically located inside the furnace access panel or in the user manual. You can also download PDF versions from the Lennox website or contact authorized service providers.

Q2: Can I wire my Lennox furnace myself?

A2: Basic wiring tasks can be performed by knowledgeable DIY enthusiasts, but for safety and compliance reasons, complex wiring or troubleshooting should be handled by licensed HVAC professionals.

Q3: What should I do if my furnace isn't igniting?

A3: Check the wiring to the ignition system, ensure the gas supply is functioning, verify safety switches are engaged, and test the control board for faults.

Q4: How often should I inspect the wiring of my Lennox furnace?

A4: Regular inspections should be performed annually during routine maintenance to identify any wear, corrosion, or loose connections.

Conclusion

A thorough understanding of the Lennox furnace wiring schematic is vital for safe operation, efficient troubleshooting, and proper maintenance. By familiarizing yourself with the wiring diagram, key components, and troubleshooting procedures, you can ensure your furnace functions reliably throughout the cold season. Always prioritize safety, follow manufacturer specifications, and consult professional technicians for complex wiring tasks or repairs. Properly wired Lennox furnaces not only provide comfort but also operate efficiently, saving energy and preventing costly repairs in the long run.

Lennox Furnace Wiring Schematic: An In-Depth Guide for Proper Installation and Troubleshooting

Understanding the wiring schematic of a Lennox furnace is essential for technicians, homeowners, and HVAC professionals aiming to ensure safe, efficient, and reliable operation of the heating system. A comprehensive grasp of the wiring layout not only facilitates proper installation but also simplifies troubleshooting and repairs. In this detailed review, we will explore the Lennox furnace wiring schematic from basic principles to advanced troubleshooting techniques, ensuring you have a complete knowledge base for working with these systems.

Introduction to Lennox Furnace Wiring Schematics

Wiring schematics serve as the blueprint for the electrical connections within a Lennox furnace. They illustrate how various components—including the thermostat, control board, blower motor, igniter, and safety devices—are interconnected. A clear schematic allows technicians to identify wiring paths, troubleshoot faults, and perform upgrades or repairs efficiently.

Key Objectives of Understanding the Wiring Schematic:

- Ensuring safety during installation or repair
- Confirming proper wiring connections
- Diagnosing electrical malfunctions
- Maintaining compliance with electrical codes
- Facilitating system upgrades or modifications

Basic Components and Their Roles in a Lennox Furnace

Before diving into the schematic itself, it's important to understand the primary components involved

in a Lennox furnace's wiring system:

1. Thermostat

- Acts as the user interface to control heating operation.
- Sends low-voltage signals (typically 24V) to start the furnace.

2. Control Board

- The brain of the furnace, managing operation based on inputs.
- Contains relays, safety switches, and diagnostic LEDs.

3. Transformer

- Converts 120V or 240V main power to 24V low-voltage supply.
- Provides power to the control board and thermostat.

4. Ignition System

- Includes hot surface igniters or spark igniters.
- Responsible for igniting the gas burner.

5. Gas Valve

- Opens to allow gas flow when the system calls for heat.

6. Blower Motor

- Circulates heated air through the ductwork.
- May be controlled via the control board or a separate relay.

7. Safety Devices

- Limit switches, flame sensors, pressure switches, etc.

- Shut down the system if unsafe conditions are detected.

Understanding how these components connect within the schematic forms the foundation for further analysis.

Deciphering the Lennox Furnace Wiring Schematic

The wiring schematic is typically represented as a diagram with symbols, lines, and labels indicating electrical connections. Here's a step-by-step method to interpret these schematics effectively:

1. Identify Power Supply Connections

- Usually marked with "L1" (hot line) and "L2" (neutral or return).
- The transformer connects across these to step down voltage.
- Confirm the input voltage matches the furnace specifications.

2. Trace the Low-Voltage Control Circuit

- Originates from the thermostat contacts.
- The thermostat, when calling for heat, closes the circuit, energizing the control board.
- Look for labels like "R" (power) and "W" (heat call).

3. Examine the Thermostat Wiring

- Typically color-coded (e.g., red for R, white for W, yellow for Y, etc.).
- Verify connections match the schematic to ensure correct operation.

4. Follow the Control Board Wiring

- The control board contains multiple relays and terminals.
- Common terminals include:
 - R: 24V power from transformer
 - W: Heat call from thermostat
 - G: Fan control
 - Y: Cooling (if applicable)
 - C: Common wire for 24V power return

5. Understand Safety Switches and Limiters

- Safety devices are wired in series with the control circuit.
- For example, a limit switch interrupts power if the furnace overheats.

6. Trace the Ignition System Wiring

- The control board energizes the igniter or spark module.
- Follow the wiring from the board to the igniter, gas valve, and associated sensors.

7. Analyze the Blower Circuit

- The blower motor may be wired directly to the control board or via relays.
- Confirm wiring to fan limit switches and speed controls if present.

Typical Wiring Diagram Components and Their Connections

A Lennox furnace schematic generally includes the following key wiring pathways:

a) Power Supply Line:

- Connects to the furnace's main terminal block.
- Feeds the transformer and other components.

b) Transformer Wiring:

- Primary side connected across L1 and L2.
- Secondary (24V) side supplies control circuit power.

c) Thermostat to Control Board:

- R (power) terminal connected to the R terminal on the control board.
- W (heat call) terminal wired to W on the control board.
- G (fan) and other signals connected accordingly.

d) Control Board to Igniter and Gas Valve:

- The control board energizes the igniter circuit.
- Gas valve is controlled via a relay on the control board.

e) Blower Motor Wiring:

- Connected via relay or directly controlled by the control board.
- May have separate high-voltage wiring depending on the furnace model.

f) Safety Switches:

- Wired in series with the control circuit to ensure safety shutdowns.

Common Wiring Configurations and Variations

While many Lennox furnaces follow a standard wiring schematic, variations can occur based on model, features, and optional accessories.

- Single-Stage Furnaces

- Simpler wiring with fewer relays.
- Typically involve a straightforward connection from thermostat to control board, igniter, and blower.

- Two-Stage Furnaces

- Additional wiring for second-stage operation.
- Might include extra relays or control board terminals.

- High-Efficiency Models

- May incorporate additional sensors, such as condensate sensors or advanced diagnostics.
- Extra wiring for these components.
- Models with Variable-Speed Blowers
- Require specific wiring for variable-speed control modules.

Understanding these variations is crucial for accurate wiring, troubleshooting, and system upgrades.

Wiring Safety and Best Practices

Maintaining safety is paramount when working with furnace wiring schematics. Here are some best practices:

- **Power Off Before Work:** Always disconnect power before inspecting or modifying wiring.
- **Use Proper Tools:** Insulated screwdrivers, wire strippers, and multimeters.
- **Follow the Schematic:** Refer to the specific Lennox model's wiring diagram for accurate connections.
- **Verify Connections:** Double-check wire colors, terminal labels, and connections after installation.
- **Secure Wiring:** Use proper clamps and connectors to prevent shorts or disconnections.
- **Label Wires:** During troubleshooting or repairs, label wires for clarity.
- **Understand Safety Devices:** Recognize how limit switches, pressure switches, and flame sensors are wired into the circuit.

Troubleshooting Using the Wiring Schematic

A detailed wiring schematic is invaluable for diagnosing issues:

Common Troubleshooting Steps:

- **Verify Power Supply:**
 - Check L1 and L2 connections.
 - Confirm transformer output (24V) with a multimeter.

- Check Thermostat Operation:
 - Ensure the thermostat is calling for heat (contacts closed).
 - Use a multimeter to test voltage at R and W terminals.

- Inspect Control Board Connections:
 - Look for loose or damaged wires.
 - Confirm relay operation when the system is called to run.

- Test Safety Switches and Limiters:
 - Use multimeter to verify continuity.
 - Replace or reset if tripped.

- Assess Ignition Circuit:
 - Check for proper voltage at igniter terminals.
 - Confirm igniter is functioning and not cracked or broken.

- Examine Gas Valve Activation:
 - Ensure the control board energizes the gas valve relay.
 - Check for gas supply issues if no ignition occurs.

- Evaluate Blower Circuit:
 - Confirm blower motor wiring and relay operation.
 - Check fan limit switches for proper operation.

Common Issues Related to Wiring Errors

Incorrect wiring can lead to various problems:

- No Heat or No Ignition: Faulty wiring to the igniter or gas valve.
- Blower Runs Continuously: Wiring issues with the fan relay or thermostat.
- System Tripping or Short Circuits: Loose or damaged wires, incorrect grounding.
- Error Codes on Control Board: Wiring faults can trigger diagnostic LEDs or error codes.

Proper adherence to the schematic and wiring standards prevents these issues.

Conclusion and Final Tips

Mastering the Lennox furnace wiring schematic is essential for safe operation, effective troubleshooting, and system longevity. Whether installing a new furnace, upgrading components, or diagnosing faults, a thorough understanding of the schematic allows you to work confidently and accurately.

Final Tips:

- Always refer to the specific model's wiring diagram provided in the service manual.
- Document existing wiring before making changes.
- Use color codes and labels to keep wiring organized.
- Test

Question What are the key components shown in a Lennox furnace wiring schematic? A Lennox furnace wiring schematic typically includes components such as the thermostat, control board, blower motor, igniter, limit switches, gas valve, and various relays and transformers, all interconnected to ensure proper furnace operation. **Answer** How can I identify the wiring terminals on a Lennox furnace control board? The wiring terminals on a Lennox furnace control board are usually labeled with abbreviations like R (power), C (common), W (heat), G (fan), Y (cooling), and others. Refer to the schematic diagram provided with your model to match each terminal accurately. What precautions should I take before working on a Lennox furnace wiring schematic? Before working on the wiring schematic, always turn off the power supply to the furnace, disconnect all electrical sources, and use a multimeter to verify there's no voltage present. Follow safety guidelines to prevent electrical shock or damage. How do I troubleshoot wiring issues in a Lennox furnace based on the schematic? Use the wiring schematic to trace the electrical pathways and check for continuity, loose connections, or damaged wires. Verify that all components receive power and signals as indicated, and consult the schematic to identify where faults may occur. Are there

differences in wiring schematics between different Lennox furnace models? Yes, wiring schematics can vary between Lennox furnace models due to differences in control systems, features, and component configurations. Always refer to the specific schematic for your model to ensure accurate troubleshooting and wiring procedures. Where can I find the official wiring schematic for my Lennox furnace? Official wiring schematics for Lennox furnaces can typically be found in the user manual or technical service manual provided by Lennox. They are also available on the Lennox website or through authorized HVAC parts distributors.

Related keywords: Lennox furnace wiring diagram, Lennox furnace wiring diagram pdf, Lennox furnace wiring, Lennox furnace wiring schematic diagram, Lennox furnace wiring instructions, Lennox furnace wiring color code, Lennox furnace control wiring, Lennox furnace wiring troubleshooting, Lennox furnace wiring diagram download, Lennox furnace wiring diagram 24V

Lennox evaporator coil part numbers

lennox evaporator coil part numbers are essential identifiers for HVAC professionals and homeowners seeking to replace or upgrade their air conditioning systems. These part numbers serve as a precise reference to specific evaporator coil models, ensuring compatibility with existing units and optimal performance. Understanding Lennox evaporator coil part numbers is crucial for accurate ordering, efficient repairs, and maintaining system efficiency. In this comprehensive guide, we will explore the significance of these part numbers, how to interpret them, and provide detailed information to help you navigate the world of Lennox evaporator coils with confidence.

Understanding Lennox Evaporator Coil Part Numbers

What Are Lennox Evaporator Coil Part Numbers?

Lennox evaporator coil part numbers are alphanumeric codes assigned to each coil model. These codes encode vital information about the coil's specifications, such as size, configuration, capacity, and compatibility. They help HVAC technicians and consumers identify the correct replacement part quickly and accurately.

Why Are Part Numbers Important?

The importance of knowing Lennox evaporator coil part numbers cannot be overstated. Proper identification ensures:

- Compatibility with existing HVAC equipment
- Accurate ordering of replacement parts
- Prevention of costly mistakes or mismatched components
- Maintenance of system efficiency and longevity
- Ease of warranty claims and technical support

Deciphering Lennox Evaporator Coil Part Numbers

Common Structure of Lennox Part Numbers

Lennox uses a systematic approach to assign part numbers, often combining letters and numbers that convey specific details about the coil. While variations exist, most part numbers follow a recognizable format, such as:

- X-AABBCC-XX
- X-AABBCC

Where:

- X represents size or capacity
- AA indicates coil configuration
- BB specifies the model series
- CC details the coil's dimensions or features

Key Elements Encoded in the Part Number

Below are the primary components typically found in Lennox evaporator coil part numbers:

- Model Series (e.g., CBX25, CBX32)
- Indicates the series or generation of the coil
- Reflects design features and technological updates
- Capacity and Size (e.g., 3, 4, 5 Tons)

- Denotes the cooling capacity
- Corresponds with the size of the coil and the system it is designed for
- Configuration Type (e.g., Horizontal, Vertical, Upflow)
- Specifies the coil orientation and airflow direction
- Critical for proper system installation
- Fin and Tube Specifications
- Encoded details about fin density, tube diameter, and materials
- Affects heat exchange efficiency and durability
- Special Features or Options
- Includes coatings for corrosion resistance, special connections, or enhanced airflow features

Examples of Lennox Evaporator Coil Part Numbers

Sample Part Number Breakdown

Let's analyze a typical Lennox evaporator coil part number:

CBX25-4P-36

- CBX25: Model series indicating the coil's design and technological features
- 4P: 4-ton capacity with a particular configuration
- 36: Dimension or specific feature code, such as coil width in inches

Interpreting the Example

- The CBX25 series is known for efficiency and compatibility with high-efficiency systems.
- The 4P designation confirms it is a 4-ton coil, suitable for medium to large residential or light

commercial systems.

- The 36 indicates the coil's width or specific design features, which must match the system's requirements.

How to Find the Correct Lennox Evaporator Coil Part Number

Steps for Accurate Identification

To ensure you select the correct evaporator coil part number, follow these steps:

- Check Existing Equipment Labels

- Locate the model and serial number on your current HVAC system.
- Look for manufacturer labels on the coil or indoor unit.

- Consult the Manufacturer's Documentation

- Refer to the system's manual or installation guide.
- Many manuals include a section on coil identification and part numbers.

- Measure the Existing Coil

- Measure dimensions such as the width, height, and depth.
- Note the coil's orientation and configuration.

- Identify Capacity Requirements

- Determine the cooling BTU/hr or tonnage needed.
- Match with the capacity codes in the part number.

- Contact Lennox or a Licensed HVAC Professional

- Provide all gathered information.
- Verify the compatibility and availability of the correct part number.

Common Lennox Evaporator Coil Part Numbers and Their Applications

Popular Models and Their Features

Below are some frequently used Lennox evaporator coil part numbers, along with their typical applications:

- CBX25-4P-36
 - Capacity: 4 Tons
 - Features: High efficiency, corrosion-resistant coatings
 - Application: Residential or light commercial systems requiring reliable performance
- CBX32-5P-48
 - Capacity: 5 Tons
 - Features: Heavy-duty construction, enhanced airflow
 - Application: Larger residential or small commercial systems
- CBX20-3P-30
 - Capacity: 3 Tons
 - Features: Compact design, standard efficiency
 - Application: Compact spaces, smaller systems

Maintenance and Replacement Tips for Lennox Evaporator Coils

Ensuring Longevity of Your Lennox Evaporator Coil

Proper maintenance extends the lifespan of your evaporator coil and maintains system efficiency:

- Regularly inspect for corrosion or damage
- Clean the coil fins with a soft brush or coil cleaner
- Ensure proper airflow to prevent dirt buildup
- Replace filters regularly to avoid contaminants
- Schedule annual professional maintenance

When to Replace Your Lennox Evaporator Coil

Signs indicating the need for a replacement include:

- Persistent refrigerant leaks
- Significant corrosion or physical damage
- Reduced cooling performance
- Unusual noises during operation
- Frequent system breakdowns

Always verify the correct part number before replacement to ensure compatibility and optimal performance.

Conclusion

Understanding Lennox evaporator coil part numbers is fundamental for proper HVAC system maintenance, repair, and replacement. These part numbers encode vital information about the coil's capacity, configuration, and features, enabling technicians and homeowners to make informed decisions. By familiarizing yourself with how to interpret these codes and following proper identification procedures, you can ensure your system operates efficiently and reliably for years to come. Whether you're replacing an old coil or upgrading to a more efficient model, always consult with a licensed HVAC professional to confirm the correct part number and installation process. Proper selection and maintenance of Lennox evaporator coils will contribute significantly to the comfort, efficiency, and longevity of your heating and cooling system.

Lennox Evaporator Coil Part Numbers: A Comprehensive Guide for HVAC Professionals and Homeowners

When it comes to maintaining and optimizing your HVAC system, understanding the components involved is crucial—especially the evaporator coil. For Lennox systems, the evaporator coil part numbers are more than just identifiers; they are keys to ensuring compatibility, efficiency, and longevity of your cooling system. In this in-depth review, we will explore the significance of Lennox evaporator coil part numbers, how to interpret them, and what factors to consider when selecting the right coil for your HVAC setup.

Understanding the Role of the Evaporator Coil in HVAC Systems

Before diving into Lennox-specific part numbers, it's important to grasp the fundamental role of the evaporator coil in an air conditioning system.

What Is an Evaporator Coil?

The evaporator coil is a vital component of the air conditioning cycle. Located inside the air handler or furnace, it works in tandem with the compressor and condenser coil to remove heat and humidity from indoor air. When refrigerant enters the coil as a low-pressure, cold liquid, it absorbs heat from the indoor air passing over it, causing the refrigerant to evaporate into a gas. This process cools the air, which is then circulated back into the living space.

Importance of Properly Specified Coils

Selecting the right evaporator coil ensures:

- Optimal cooling performance
- Energy efficiency
- System longevity
- Compatibility with existing equipment

Incorrect or incompatible coils can lead to reduced efficiency, increased energy costs, or system failure.

Deciphering Lennox Evaporator Coil Part Numbers

Lennox, a renowned manufacturer in HVAC, employs a systematic approach to assign part numbers to its evaporator coils. These part numbers encode essential details about the coil's specifications, ensuring that technicians and homeowners can identify and select the right component.

The Structure of Lennox Part Numbers

Lennox coil part numbers are typically alphanumeric codes, often following a specific pattern, which includes information about:

- Series and model family
- Size and capacity
- Configuration (e.g., number of rows, coil type)
- Special features (e.g., fin type, coil dimensions)

While exact formats can vary across product lines, most follow a logical structure that allows for easy identification.

Example of a Lennox Evaporator Coil Part Number:

> 13B48

Breaking down the example:

- 13: Series or model family
- B: Configuration or coil type
- 48: Specific size or capacity code

(Note: Lennox's actual part numbering system can be more complex, often including additional identifiers like model numbers or special features. Always consult the official Lennox documentation for precise decoding.)

Common Elements in Lennox Part Numbers

- Series Identifier: Indicates the product line or series (e.g., 13, 14, 15)
- Configuration Code: Denotes coil arrangement or type (e.g., B for horizontal, A for vertical)
- Size/Capacity Code: Represents the coil size or cooling capacity, often based on tonnage
- Additional Features: May include indicators for fin type, coil material, or specific features like enhanced corrosion resistance

Categories of Lennox Evaporator Coils and Their Part Numbers

Lennox offers a variety of evaporator coils tailored to different system sizes and configurations. Understanding these categories helps in selecting the correct part number.

Residential Coils

Designed for standard home HVAC systems, residential coils generally have the following characteristics:

- Size Range: Typically 1 to 5 tons
- Configuration: Horizontal or vertical face types
- Part Number Examples:
 - 13B48 (for a 2-ton horizontal coil)
 - 14B36 (for a 1.5-ton vertical coil)

Key Features:

- Copper tubes with aluminum fins for efficient heat transfer
- Pre-drilled holes and mounting brackets for ease of installation
- Compatibility with various Lennox air handlers and furnaces

Commercial Coils

Commercial coils are more robust, accommodating higher capacities and specialized configurations:

- Size Range: Up to 20+ tons
- Configurations: Multi-row, custom-fitted units
- Part Number Examples:
 - 15B60 (for a large capacity, multi-row coil)
 - 16A72 (custom configurations)

Features:

- Heavy-duty construction with options for stainless steel or other corrosion-resistant materials
- Designed for integration into larger HVAC systems
- Enhanced durability for prolonged outdoor exposure

Factors Influencing Coil Part Number Selection

Choosing the correct Lennox evaporator coil involves more than matching a part number; it requires understanding system compatibility and environmental factors.

System Compatibility

- Matching Capacity: The coil must match the system's BTU/hr capacity. An undersized coil won't cool effectively, while an oversized one wastes energy.
- Air Handler Compatibility: Ensure the coil fits within existing air handler dimensions and mounting points.
- Refrigerant Type: Confirm the coil is compatible with the refrigerant used in your system (e.g., R-410A vs. R-22).

Installation and Orientation

- Horizontal vs. Vertical: Select a coil configuration that fits your installation space.
- Indoor or Outdoor Use: Some coils are designed for outdoor exposure with corrosion-resistant features.

Environmental Considerations

- Corrosion Resistance: Use coils with enhanced fins or coatings in coastal or high-humidity environments.
- Finned Material: Aluminum fins are standard, but stainless steel fins may be preferred for corrosive conditions.

Efficiency and Performance Features

- Fin Design: Enhanced fin designs improve heat transfer efficiency.
- Coil Material: Copper tubing offers superior thermal conductivity.

Where to Find Lennox Evaporator Coil Part Numbers

Locating the correct part number involves reviewing:

- Existing Equipment Labels: The original coil or system label often displays the part number.
- Owner's Manual: Manufacturer documentation may include part number references.
- Lennox Technical Support: Contact Lennox or authorized dealers for assistance.
- Online Resources: Lennox's official website and authorized distributor catalogs often list detailed part information.

Conclusion: The Importance of Accurate Part Number Identification

Understanding Lennox evaporator coil part numbers is vital for ensuring system compatibility, optimal performance, and long-term reliability. Whether you're a professional HVAC technician or a knowledgeable homeowner, recognizing how to interpret these codes can streamline repairs, replacements, and system upgrades.

Always verify part numbers against system specifications and consult Lennox's official resources or professionals when in doubt. Investing time in understanding these identifiers ensures your HVAC system operates efficiently and effectively, providing comfort and energy savings for years to come.

Final Tips for Selecting Lennox Evaporator Coils:

- Double-check the existing coil's part number before ordering.
- Consider environmental factors that may influence coil material choice.
- Consult Lennox's technical support for complex or custom configurations.
- Prioritize compatibility with your current system to avoid costly mismatches.

By mastering the nuances of Lennox evaporator coil part numbers, you empower yourself with the knowledge to make informed decisions and maintain a high-performance HVAC system that meets your needs.

Question How can I find the correct Lennox evaporator coil part number for my model? To find the correct Lennox evaporator coil part number, check the existing coil for a label or tag that lists the model and serial numbers. You can also consult your HVAC system's manual or contact a licensed technician with your system details for accurate part identification. **Are Lennox evaporator coil part numbers interchangeable between different models?** Lennox evaporator coil part numbers are specific to certain models and configurations. While some parts may be compatible across similar units, it's essential to verify compatibility with your specific system by consulting Lennox's parts catalog or a professional technician. **Where can I purchase Lennox evaporator coils using the part number?** You can purchase Lennox evaporator coils through authorized Lennox dealers, HVAC supply stores, or online retailers that specialize in HVAC parts. Always verify the part number to ensure compatibility with your system before purchasing. **What should I do if I can't find the part number on my Lennox evaporator coil?** If the part number is missing or unreadable, contact a licensed HVAC technician who can identify the coil based on its physical characteristics and model details. Providing your system model number and installation date can also help in sourcing the correct replacement part. **Are Lennox evaporator coil part numbers the same for residential and commercial units?** No, Lennox evaporator coil part numbers typically differ between residential and commercial units due to different specifications and sizes. Always verify the part number against your specific system type to ensure proper fit and performance.

Related keywords: Lennox evaporator coil, Lennox coil model numbers, Lennox coil part numbers, Lennox HVAC components, Lennox AC evaporator coil, Lennox replacement coils, Lennox coil specifications, Lennox coil identification, Lennox coil compatibility, Lennox coil catalog

Read the full article online: [Lennox evaporator coil part numbers](#)